


MATERIAL CHEMISTRY:

CSE-A

- 1) Derive Nernst Equation for $\alpha A + bB \rightarrow cC + dD$ (reversible reaction). And write its applications:

Ans: Given equation / reaction:



Let E° be the standard electrode potential of the above reaction:

E° = Standard electrode potential

E = Electrode potential

→ Nernst Equation gives the relation between E and E° :

$$\Delta G = -\text{Work}$$

$$\text{Work} = \text{Electrical energy} = n \cdot F \cdot E$$

where ΔG = Gibb's free energy

n = charge transfer e.s.

$F = 96500$

E = Potential of the electrodes

∴ $\boxed{\Delta G = -nFE}$ and at standard conditions: $\boxed{\Delta G^\circ = -nFE^\circ}$

→ Vanthoff's Isotherm equation:

$$\Delta G = \Delta G^\circ + RT \ln Q$$

$$-nFE = -nFE^\circ + RT \ln Q$$

$$\boxed{E = E^\circ - \frac{RT}{nF} \ln Q}$$

For equilibrium equation/reaction $\Rightarrow K \neq 0$

where

$$K = \frac{[C]^c [D]^d}{[A]^a [B]^b}$$

equilibrium Constant.

$$E = E^\circ - \frac{2.303 RT}{nF} \log \left(\frac{[C]^c [D]^d}{[A]^a [B]^b} \right)$$

where $R = 8.314$; $T(K) = 300K$; $F = 96500F$

$$\Rightarrow E = E^\circ - \frac{2.303 RT}{nF} \log K$$

$$\therefore K_e = \frac{P}{[R]}$$

$$E = E^\circ - \frac{0.059}{n} \log \frac{KP}{[R]} \rightarrow \text{Electrolytes}$$

→ Applications:


- 1) We can determine E when we have the value E° and vice versa at any given conditions of temperatures
- 2) We can calculate Gibbs free energy from the value of E .
- 3) We can determine the equilibrium constant from the Nernst equation.
- 4) We can check the feasibility of the cell.
- 5) Find the concentration of the electrolytes (or) the ratio.
- 2) Describe the construction of Quinhydrone electrode. Derive its Nernst equation. Write its electrode reaction, notation and write its limitations.

S:


Quinhydrone electrode: is a REDOX ELECTRODE:

* Quinhydrone powder

= Quinone + Hydroquinone



* Electrode Reaction:



* In Redox Electrode; electrode potential is developed due to the inter conversion of the same compound by oxidation and reduction.

- Platinum electrode is acting as a conductor.

* ANODE: Pt, Q, QH₂ | H⁺

(s) (s) (l)

* CATHODE: H⁺ | Q, QH₂, Pt

(l) (s) (s)

* Nernst Equation: $E_{QE}^\circ = 0.699 \text{ V}$

$$E_{QE} = E_{QE}^\circ - \log \frac{[\text{QH}_2]}{[\text{Q}][\text{H}^+]^2} \times \frac{0.059}{2}$$

∴ QH₂ and Q are in solid state $[\text{QH}_2] = 1$; $[\text{Q}] = 1$

$$\therefore E_{QE} = 0.699 - \frac{0.059}{2} \log \frac{1}{[\text{H}^+]^2}$$

$$E_{QE} = 0.699 + \frac{0.059}{2} \log [\text{H}^+]$$

$$= 0.699 - 0.059 (-\log [\text{H}^+])$$

$$E_{Q.E} = 0.699 - 0.059 \text{ pH}$$

$$\text{pH} = -\log(H^+) = p^n$$

∴ Quinhydrone electrode acts as pH indicator.

→ Limitations:



- 1) This electrode cannot be used as reference electrode since it is not reliable.
- 2) The electrolyte used should be free of oxidising agents and reducing agents; because these will disturb the equilibrium.
- 3) Discuss the factors effecting the conductance and explain any a conductometric titrations with well labelled graphs.

Ans Factors effecting the conductance:

- 1) Nature of electrolyte → S.E
 - 2) Solvent → WE
 - 3) Temperature
 - 4) Concentration / no. of ions
 - 5) Mobility of ions.
- Remains constant once the experiment starts.

* Titration between strong acid and strong base:

Here, HCl and NaOH are strong acid and strong base respectively which are also strong electrolytes which undergo dissociation to form respective ions which are necessary to cause a change in the conductance.



* ∵ No. of H^+ ions decreases.

and Na^+ is heavier than H^+ .

\therefore Mobility of ions decreases; thereby conductance is decreased by the time titration is completed; it becomes minimum.


→ But no. of ions in the beaker remains same.

→ Till the point at which HCl is completely neutralised no. of ions decreases and thereby from that point no. of ions increases, & hence increasing the conductance.

$$*\sqrt{NaOH} = E \cdot P$$

$$N_{\text{HCl}} = \frac{(N \vee)_{\text{NaOH}}}{V_{\text{HCl}}}$$


$$* \text{Wt}_{\text{HCl}} = \text{N}_{\text{HCl}} \times \text{Eq. Wt of HCl.}$$



* The equivalence point where the reaction just completed gives the volume of NaOH .

* Titration of mixture of acids:

- Titration of mixture of acids consists of 2 acids i.e. a strong acid (HCl) and weak acid (CH_3COOH) which have an ion in common which undergoes common ion effect during the titration.
- * Common Ion effect: It is defined as the common ion formed when a strong acid and a weak acid are mixed; the dissociation of weak acid is suppressed.
- HCl undergoes neutralisation initially whereas CH_3COOH do not undergo neutralisation due to common ion effect i.e. Neutralisation of CH_3COOH (WA) is suppressed.
- Once HCl is neutralised completely, the solution in the beaker acts as a pure acetic acid sol'; wherein conductance rises.
- $a = \sqrt{\text{NaOH}}$ required to neutralise HCl.



$$b = \sqrt{\text{NaOH}} \text{ required to neutralise } \text{HCl} + \text{CH}_3\text{COOH}$$

$$b - a = \sqrt{\text{NaOH}} \text{ required to neutralise } \text{CH}_3\text{COOH}$$

$$N_{HCl} = \frac{(N V)_{NaOH}}{\sqrt{HCl}}$$

* Wt. of HCl

$$= N_{HCl} \times 36.5 \text{ g/L}$$

$$N_{CH_3COOH} = \frac{(N V)_{NaOH}}{\sqrt{CH_3COOH}}$$

* Wt. of CH₃COOH

$$= N_{CH_3COOH} \times 60 \text{ g/L}$$

- 4) Discuss the construction, chemistry, and applications of any one primary, secondary and fuel cell, mention their advantages over others.

* PRIMARY BATTERY: Zinc-Carbon Battery:

→ Construction:

* Cathode: Graphite Rod.

* Anode: Zinc Rod.



* Cathodic Material: Mn₂O₃ + graphite

* Anodic Material: (Zn + ZnO + graphite) powder.


* Electrolyte: Aqueous Ammonium Chloride (NH₄Cl).



→ The anode & cathode materials are made into paste so as to avoid reactions.

* Cell Notation:



* Cell Reactions:






→ Cathode:



$$\boxed{\text{VOLTAGE} = 1.5\text{V}}$$



* Total reaction:



* Applications:

- 1) Remote controls for television, clocks, smoke detectors and flashlights.
- 2) Hand cranked telephone magneto phones; powering microphone & speaker.

* Features:

- Inexpensive, widely available
- Inefficient at high current drain
- Poor discharge curve
- Poor performance at low & high temperatures

* SECONDARY BATTERY: Lead Acid Battery:

$$\boxed{\text{VOLTAGE} = 2\text{V}}$$

→ Construction:



* Anode: lead

* Cathode: lead di-oxide

* Electrolyte: sulphuric acid (specific gravity = 1.2)

Separator: Polymer (polypropylene) sheet



* Cell Notation:





* Cell Reactions:

During discharge: Galvanic Cell → ebonite rubber


- Spontaneous redox reaction:



deposited on lead plate.



Total Reaction:



* During charging reactions are exactly opp. to the above.

* Applications:

1) Used in back-up power supplies for alarms; for electric scooters, wheelchairs.

2) Also used in marine applications; micro hybrid vehicles.

* Features:

- Low self discharge

- cannot be stored when discharged.

- 40% in one year.

* FLOW BATTERY: $\text{CH}_3\text{OH} - \text{O}_2$ FUEL CELL

- Low Temperature Fuel Cell and Alkaline Fuel Cell.

→ Construction:


- * Fuel: Methanol
- * Oxidant: Oxygen
- * Electrolyte: KOH (liquid)
- * Anode: Porous Ni impregnated with Pt/Pd catalyst

Cathode: Porous Ni coated with silver catalyst.



- * Catalysts: Pt/Pd & Ag

* Operating temperature: $40 - 90^\circ\text{C}$.


Fuel cell efficiency: $40 - 45\%$.



* Cell Reactions:



Total reaction:



* Applications:

- 1) Power for man-portable tactical equipment, battery chargers.
- 2) Autonomous power for test-training instrumentation.


* Features:

- Products formed i.e. CO_2 is not dangerous compared to the products formed during burning coal i.e. $\text{CO}, \text{SO}_2, \text{SO}_3, \text{NO}_x$.

* NUMERICALS:


- I) Calculate the standard EMF of a cell containing Sn^{+2}/Sn and Br_2/Br^- electrodes.

$$E^\circ(\text{Sn}^{+2}/\text{Sn}) = 0.14 \text{ V} \quad E^\circ(\text{Br}_2/\text{Br}^-) = 1.08 \text{ V}$$






$$\begin{aligned} \therefore E_{\text{cell}} &= E_c - E_A \\ &= 1.08 - 0.14 \\ &= \underline{\underline{0.94 \text{ V}}} \end{aligned}$$

2) Calculate E_{cell}° when the following half cell reactions are combined:



Net reaction:



$$\begin{aligned} E_{\text{cell}}^{\circ} &= E_c - E_A \\ &= 1.49 - 0.77 \\ &= \underline{\underline{0.72\text{ V}}} \end{aligned}$$

3) Calculate the equivalent conductivity of 1M H_2SO_4 solution whose conductivity is $26 \times 10^{-2} \text{ ohm}^{-1}\text{cm}^{-1}$

$$\lambda_M = \frac{K \times 1000}{M}$$

$$K = 26 \times 10^{-2}$$

$$\lambda_{\text{eq}} = \frac{K \times 1000}{N}$$

$$= \frac{26 \times 10^{-2} \times 10^3}{2} \times \chi$$

$$\lambda_{\text{eq}} = 13 \times 10^2 = 1.3 \times 10^2 \text{ ohm}^{-1}\text{eq}^{-1}$$

$$N = \frac{M \times F}{2} = 2 \times 1$$


4) Construct a concentration cell with Nickel electrodes. The electrode potential of Ni° is -0.24V and the concentrations of solutions are 0.5 and 0.05 respectively.

$C_1 = 0.05 \rightarrow$ Anode

Oxidation


$C_2 = 0.5 \rightarrow$ Cathode

Reduction



$E^\circ_{\text{cell}} = 0 \because$ for any concentration cell.

$$E = -\frac{0.0591}{n} \log \frac{C_1}{C_2}$$



$$= -\frac{0.0591}{2} \log \frac{0.05}{0.5}$$

$$= -\frac{0.0591}{2} \log \frac{5 \times 10^{-2}}{5 \times 10^{-1}}$$

$$= -\frac{0.0591}{2} \times -1 = 0.029\text{V}$$

$E = 0.029\text{V}$